

# Back To Wall Toilet Planning Checklist

What to confirm before you install, from Kitchen and Bath Reno

## Before you decide

### 1 Confirm you are renovating, not just swapping

The design pays off most when the wall is already open.

### 2 Measure the depth you can give up

Expect the finished wall to move out by roughly 5 to 15 cm.

### 3 Decide on the look and budget

Weigh the cleaner built-in look against the added cost.

## Planning the install

### 1 Check the wall can carry a frame

A solid stud or support wall is needed for the cistern.

### 2 Choose the flush-plate location and access

Keep the service hatch reachable behind the plate.

### 3 Set the pan height for your household

Built-in support lets you pick a comfortable height.

### 4 Confirm the waste outlet position

Moving a drain adds labour and may need a permit.

## Getting it done right

### 1 Use a licensed plumber

Plumbing connections and any drain relocation are licensed work.

### 2 Coordinate the trades

Plumber, tiler, and carpenter all touch this fixture; sequence matters.

**Planning a kitchen or bathroom renovation in Mississauga and the GTA? We can help.**

[kitchenandbathreno.ca/contact/](https://kitchenandbathreno.ca/contact/) | Call (905) 277-2228 | Serving Mississauga and the GTA